



PRODUCT REQUIREMENT DOCUMENT

Handset UI • Features & Applications - Launch



CONTENTS INCLUDE:

Customer User Interface

Sitemap	2
Idle Screen	3
Camera	4
Message Center	5

Family First Phonebook

6 Key features of the Family First Phonebook	6
Prioritizing Family Members	7
Presence	8
Character Caller ID	9
Parental Controls	10
Location Services	11
Family Message Board	12

Disney Quicklinks

6 Key Features of the Disney Quicklinks	13
Phone Flicks	14
Games	15
Daily Disney	16
Personalize	17
Send a Message	18
Download Zone	19

MAIN MENU ITEMS

Applications

Menu Scrolling	20
Family First Phonebook	21
Message Center	22
- Instant Messaging	23
Entertainment & Info	24
- Games	25
- Movies.com	26
- Phone Flicks	27
- Browser	28
Location Services	29
Camera	30
Alarm Clock	31
Calculator	32

Phone Settings

Description & Menu Items	33
--------------------------	----

Download Zone

Description & Menu Items	34
--------------------------	----

Personalize

Description & Menu Items	35
Themed UIs	36

CUSTOMER USER INTERFACE

SECTION ADDRESSES:

Sitemap


Idle Screen

Camera

Message Center

Idle Screen Tabs Connect to Disney Quicklinks and Family First Phonebook - Tabs can be turned off in Phone Settings.

Menu Disney Themed Look and Feel




IDLE SCREENS

- Easy access to Connecting the FamContentently Featres and Disney content.
- Easy access to Camera, Main Menu and Message Center.



Turning off the Screen Tabs option.




CAMERA

- Take photos, picture mail, create caller ID, create wallpaper and photo frames.



Accessing the Camera- Scenario

Final Camera navigation will be dependent on handset.



Press the CAMERA soft key on the left to access the CAMERA.




The CAMERA is now ready to snap photos. Press the center of the NAVIGATIONAL PAD to take the picture.

Or press MY PHOTOS on the right soft key.



The User can select a photo by scrolling down and pressing the SELECT soft key on the right.




The User can enter a photos options by pressing the OPTIONS soft key on the right.




MESSAGE CENTER

- Inbox, outbox, call history, voice mail, send and receive SMS, and MMS message.
- Access Family Message Board and Instant Messaging.



SEND SMS MESSAGE



Press the **MSG. CENTER** soft key on the right to access the **MESSAGE CENTER**.

Select **SEND A MESSAGE** and press the **SELECT** soft key on the right.

Select **TEXT**.

ADD ICONS



Use the 4 way directional pad to navigate to the icon box. The right soft key will change from **SEND** to **SELECT**. Select and press the right **SELECT** soft key to add the icon to the message.

SEND MMS MESSAGE




Press the **MSG. CENTER** soft key on the right to access the **MESSAGE CENTER**.

Select **SEND A MESSAGE** and press the **SELECT** soft key on the right.

Select **MULTI-MEDIA MESSAGE** and press the **SELECT** soft key on the right.

To add an animation to the message press the **ADD** soft key on the left.


Select **ANIMATED MSGS.** and press the **SELECT** soft key on the right.



Select an animation and press the **SELECT** soft key on the right.

Animation is shown.

INSTANT MESSAGING



Press the **MSG. CENTER** soft key on the right to access the **MESSAGE CENTER**.

Select **INSTANT MESSAGING** and press the **SELECT** soft key on the right.

Enter into an instant message.

FAMILY FIRST PHONEBOOK

SECTION ADDRESSES:

6 Key features of the Family First Phone Book

Prioritizing Family Members

Presence


Character Caller ID

Parental Controls

Location Services

Family Message Board

FAMILY FIRST PHONEBOOK



Default Setting for Entries:

1. Family Entries

2. Postboard

3. Other Entries

4. New Entry Button

5. Entry Reorganization


Family 1st Phonebook Functionality & User Scenario:




1. Prioritize Family Members
Family members are always at the top of phonebook list




2. Presence
Visual shows if other family members phones are on or off



3. Character Caller ID
Associate graphics or photos with family members.



4. Parental Controls
Manage spending limits on the child's phone.




5. Location Services

- Child Locator
- Child Pick-Me-Up
- People Finder



6. Family Message Board
Intra-family unified messaging. One central area to post voice and text messages for the whole family to access.

FAMILY FIRST PHONEBOOK 1. Prioritizing Family Members



Alternative ways to reorganize entries

ALPHABETICAL REORDER: List all entries in alphabetical order

In the PHONEBOOK, scroll down on the list to ENTRY REORGANIZATION and press the SELECT soft key on the right.

Select ALPHABETICAL ORDER and press the SELECT soft key on the right.

Family Message Board, New Entry, and Entry Reorganization Move down to the bottom of the list.

MANUAL REORDER: The ability to move entries up or down on the phonebook list manually.

In the PHONEBOOK, scroll down on the list to ENTRY REORGANIZATION and press the SELECT soft key on the right.


Select MANUAL REORDER and press the SELECT soft key on the right.

Select the entry to be moved and press the SELECT soft key on the right.

Using the UP and DOWN buttons, move the entry into its position and press the ACCEPT soft key on the right.

The list is now reordered.

FAMILY FIRST PHONEBOOK 2. Presence



Presence states



Arrow up indicates the users phone is ON (powered up)



Arrow down indicates the users phone is OFF (powered off)



Samantha's phone is off, thus indicated by the powered off arrow.




Samantha turns her phone on.




Samantha's Presence is updated on the fly.



FAMILY FIRST PHONEBOOK 3. Character Caller ID




Associate a Character Caller ID




Create a Photo Caller ID




FAMILY FIRST PHONEBOOK 4. Parental Controls



Parental Controls - Spending Limits User Scenario:




FAMILY FIRST PHONEBOOK 5. Location Services



Location Services - Child Finder

MOM'S PHONE



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.

From APPLICATIONS move the selection to FAMILY FIRST PHONEBOOK and press the SELECT soft key on the right.

In FAMILY FIRST PHONEBOOK, select an entry and press the SELECT soft key on the right.


...retrieving...

The display is shown. To get directions to the location, press the DIRECTIONS soft key on the right.

The directions are now displayed.

Location Services - Send Pick-Me-Up (Send Location) Sample Navigation:

KID'S PHONE




In FAMILY FIRST PHONEBOOK, select an entry and press the SELECT soft key on the right.

Select SEND PICK ME UP and press the SELECT soft key on the right.

Enter a message and press the SELECT soft key on the right.

Message sent.

MOM'S PHONE




Mom receives an alert on her phone.


From the ALERT, press the VIEW soft key on the right.

The message is now displayed. To display the location of the Message Sender, press the MAP soft key on the right.

The location is displayed.



FAMILY FIRST PHONEBOOK 6. Family Message Board



Posting Audio & Text Messages to Post Board

On the IDLE SCREEN press the directional pad to the right.

Select FAMILY MESSAGE BOARD and press the SELECT soft key on the right.

Select POST MESSAGE and press the SELECT soft key on the right.

Press the RECORD soft key on the right.

Record your message and press the END RECORD soft key on the right.

Select DONE press the SELECT soft key on the right.

New message is posted.

Receiving Audio & Text Messages from Post Board

Audio Played
 "Sarah, I am running late. Can you pick-up Joey and bring him to his baseball game. I have enclosed His coach's number."

On the IDLE SCREEN press the directional pad to the right.

Select FAMILY MESSAGE BOARD and press the SELECT soft key on the right.

Select the message and press the PLAY soft key on the right.

Select PLAY AUDIO and press the SELECT soft key on the right.

Confirmation on Post Board

On the IDLE SCREEN press the directional pad to the right.

Select FAMILY MESSAGE BOARD and press the SELECT soft key on the right.

Select the message and press the PLAY soft key on the right.

Select DETAILS and press the SELECT soft key on the right.

Details are shown.

DISNEY QUICKLINKS

SECTION ADDRESSES:

6 Key Features of the Disney Quicklinks

Phone Flicks

Games

Daily Disney


Personalize

Send a Message

Download Zone



DISNEY QUICKLINKS

- Easy access to Disney content.
- Easy access to download additional Disney content.



DISNEY QUICKLINKS 1. Phone Flicks

- **Disney Storytelling:** 17 minute audio and graphic (slideshow) story. Using existing Disney Feature animation properties. (Examples: Lilo and Stitch, Lion King)
- **Disney Shorts:** 30 second animated clip using existing Disney animated assets.
- **Quick Clips:** 30 second animated clip using The Walt Disney Company assets along with non-Disney assets. (Examples: ESPN, That's So Raven)



From the QUICKLINKS screen, select PHONE FLICKS and press the SELECT soft key on the right.



The user can then select the type of Phone Flick they wish to access.


Disney Storytelling




Disney Shorts




Quick Clips



DISNEY QUICKLINKS 2. Games



From the QUICKLINKS screen, select GAMES and press the SELECT soft key on the right.





Choose a game and press the SELECT soft key on the right.



Game is ready to play.

DISNEY QUICKLINKS 3. Daily Disney

• Daily news, information and fun. Data is specific to Disney content from parks and character properties to upcoming Feature Animations and Disney history.





From the QUICKLINKS screen, select DAILY DISNEY and press the SELECT soft key on the right.




The user can then select different information and fun from DAILY DISNEY.

DISNEY QUICKLINKS 4. Personalize

- Access to theming on your handset.



From the QUICKLINKS screen, select PERSONALIZE and press the SELECT soft key on the right.




The user can then select the item on the phone they wish to change.


Ringtones




Screensavers





Themed UI's



Wallpaper



DISNEY QUICKLINKS 5. Send a Message




From the QUICKLINKS screen, select SEND A MESSAGES and press the SELECT soft key on the right.




The user can then access what type of message they wish to send.

Send Text Message



See pg. 12 and 22 for user info.

Email



Send Multi-Media (MMS)



See pg. 12 and 22 for user info.

DISNEY QUICKLINKS 6 Download Zone

- Free access to a store front portal.
- Premium, exclusive, and free content and applications available to download.



From the QUICKLINKS screen, select Download Zone and press the SELECT soft key on the right.



The user can then select the item they wish to download to their handset .

Disney Exclusives	Disney Free Gifts	Entertainment & Info	Personalization	Animated Msgs.	Caller IDs	Applications & Fun

MAIN MENU ITEMS

APPLICATIONS

SECTION ADDRESSES:

Menu Scrolling

Family First Phonebook

Message Center

- Instant Messaging

Entertainment & Info

- Games

- Movies.com

- Phone Flicks

- Browser


Location Services

Camera

Alarm Clock

Calculator

MAIN MENU SCROLLING



APPLICATIONS

- Family First Phonebook
- Message Center
- Entertainment & Info
- Location Services
- Camera
- Alarm Clock
- Calculator

PHONE SETTINGS

- Volume
- Time and Date
- Language
- Call Answer
- Idle Screen Tabs
- Network
- Auto Answer

DOWNLOAD ZONE


- Disney Exclusives
- Disney Free Gifts
- Entertainment & Info
- Personalization
- Animated Msgs.
- Caller IDs
- Applications & Fun

PERSONALIZE


- Ringtones
- Screensavers
- Wallpaper
- Themed UIs




Normal state of the MAIN MENU.



APPLICATIONS is selected.



PHONE SETTINGS is selected.




DISNEY CLUB is selected.



PERSONALIZE is selected.

FAMILY FIRST PHONEBOOK





From MAIN MENU select APPLICATIONS then press the SELECT soft button on the right.



In APPLICATIONS select FAMILY FIRST PHONEBOOK then press the SELECT soft button on the right.




MESSAGE CENTER




SEND SMS MESSAGE




From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.




from APPLICATIONS move the selection to MESSAGE CENTER and press the SELECT soft key on the right.



Select SEND MESSAGES and press the SELECT soft key on the right.




SMS messaging allows the user to chat to others quickly.



SMS messaging allows the user to chat to others quickly.

ADD ICONS




To add an icon, use the 4 way directional pad and navigate to the icons and cursor around to select (the right softkey will change from SEND to SELECT when the icons are selected). Press the right SELECT softkey to add the icon to the message.

SEND MMS MESSAGE



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.



from APPLICATIONS move the selection to MESSAGE CENTER and press the SELECT soft key on the right.



Select SEND MESSAGES and press the SELECT soft key on the right.



Select MULTI-MEDIA MESSAGE and press the SELECT soft key on the right.



To add an animation to the message press the OPTIONS soft key on the left.



Select ANIMATIONS and press the SELECT soft key on the right.



Select an animation and press the SELECT soft key on the right.



Animation is shown.

INSTANT MESSAGING




From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.



from APPLICATIONS move the selection to MESSAGE CENTER and press the SELECT soft key on the right.



Select INSTANT MESSAGE and press the SELECT soft key on the right.



Enter into an instant message.


MESSAGE CENTER- Instant Messaging




User Scenario




From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.




From APPLICATIONS move the selection to MESSAGE CENTER and press the SELECT soft key on the right.




Select INSTANT MESSAGING and press the SELECT soft key on the right.





ENTERTAINMENT & INFO



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.




from APPLICATIONS move the selection to ENTERTAINMENT & INFO and press the SELECT soft key on the right.



ENTERTAINMENT & INFO- Games




Navigation to Games Menu




From the MAIN MENU, select **APPLICATIONS** and press the **SELECT** right soft key.




From **APPLICATIONS** move the selection to **ENTERTAINMENT/INFO** and press the **SELECT** soft key on the right.



Scroll down to **GAMES** and press the **SELECT** soft key on the right.





Choose a game and press the **SELECT** soft key on the right.



Game is ready to play.

ENTERTAINMENT & INFO- Movies.com

- Save information on your favorite movies and theaters.
- Get Updates on upcoming DVD releases.



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.




From APPLICATIONS move the selection to ENTERTAINMENT & INFO and press the SELECT soft key on the right.



Move the selection to MOVIES.COM and press the SELECT soft key on the right.




ENTERTAINMENT & INFO- Phone Flicks



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.





From APPLICATIONS move the selection to ENTERTAINMENT & INFO and press the SELECT soft key on the right.




Move the selection to PHONE FLICKS and press the SELECT soft key on the right.




The three different kinds of FLICKS can be accessed.




ENTERTAINMENT & INFO- Browser




From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.



From APPLICATIONS move the selection to ENTERTAINMENT & INFO and press the SELECT soft key on the right.



Scroll down to BROWSER and press the SELECT soft key on the right.



From this point the user can view...

- ABC.com
- ESPN.com
- Daily Disney
- and the world wide web



DAILY DISNEY





ABC News




ESPN News

LOCATION SERVICES



Get locations and Directions



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.


from APPLICATIONS move the selection to LOCATION SERVICES and press the SELECT soft key on the right.

Select GET DIRECTIONS and press the SELECT soft key on the right.

Enter your destination and press the ENTER soft key on the right.

To see the directions, press the DIRECTIONS soft key on the right.

Find Someone: Location and get directions to their location.



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.

from APPLICATIONS move the selection to LOCATION SERVICES and press the SELECT soft key on the right.

Select FIND SOMEONE and press the SELECT soft key on the right.

Enter their number and press the ENTER soft key on the right.






When being searched for, the user being found will receive a prompt.


Family Plan Users on Child's phone will not receive prompt



CAMERA



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.




From APPLICATIONS move the selection to CAMERA and press the SELECT soft key on the right.




The CAMERA is now ready to snap photos. Press the center of the NAVIGATIONAL PAD to take the picture.

Or press MY PHOTOS on the right soft key.





The User can select a photo by scrolling down and pressing the SELECT soft key on the right.



The User can enter a photos options by pressing the OPTIONS soft key on the right.



ALARM CLOCK








From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.

From APPLICATIONS move the selection to ALARM CLOCK and press the SELECT soft key on the right.

Select Alert and press the SELECT right soft key.

CALCULATOR



From the MAIN MENU, select APPLICATIONS and press the SELECT right soft key.


From APPLICATIONS move the selection to CALCULATOR and press the SELECT soft key on the right.

MAIN MENU ITEMS

PHONE SETTINGS

SECTION ADDRESSES:
Description & Menu Items

Phone Settings




Sample function Turning off the Screen Tabs option.



Press the MENU key to access the MAIN MENU.



Select PHONE SETTINGS and press the SELECT soft key on the right.



Scroll down to IDLE SCREEN TABS on/off and toggle the setting to OFF. Press the SELECT soft key on the right.




Screen Tabs are now absent.

MAIN MENU ITEMS

DOWNLOAD ZONE

SECTION ADDRESSES:
Description & Menu Items


DOWNLOAD ZONE



Select **DOWNLOAD ZONE** and press the **SELECT** soft key on the right.



The user can then select the item they wish to download to their handset.






MAIN MENU ITEMS
PERSONALIZE

SECTION ADDRESSES:


Description & Menu Items

Themed UI's

PERSONALIZE



Select PERSONALIZE and press the SELECT soft key on the right.



THEMED UIS

Themed UI - User Scenario:



Themed UI - User Scenario:

